

Crupi Gear Ratios

		20 x 1.50 (19.25" inflated diameter)																	
Gear		34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51
Free Wheel	9																		
	10	65.5	67.4	69.3															
	11	59.5	61.3	63.0	64.8	66.5	68.3	70.0											
	12	54.5	56.1	57.8	59.4	61.0	62.6	64.2	65.8	67.4	69.0	70.6							
	13	50.3	51.8	53.3	54.8	56.3	57.8	59.2	60.7	62.2	63.7	65.2	66.6	68.1	69.6	71.1			
	14	46.8	48.1	49.5	50.9	52.3	53.6	55.0	56.4	57.8	59.1	60.5	61.9	63.3	64.6	66.0	67.4	68.8	70.1
	15	43.6	44.9	46.2	47.5	48.8	50.1	51.3	52.6	53.9	55.2	56.5	57.8	59.0	60.3	61.6	62.9	64.2	65.5
	16	40.9	42.1	43.3	44.5	45.7	46.9	48.1	49.3	50.5	51.7	52.9	54.1	55.3	56.5	57.8	59.0	60.2	61.4
	17		39.6	40.8	41.9	43.0	44.2	45.3	46.4	47.6	48.7	49.8	51.0	52.1	53.2	54.4	55.5	56.6	57.8
	18				39.6	40.6	41.7	42.8	43.8	44.9	46.0	47.1	48.1	49.2	50.3	51.3	52.4	53.5	54.5
20								39.5	40.4	41.4	42.4	43.3	44.3	45.2	46.2	47.2	48.1	49.1	

Front gear size divided by Freewheel size times the inflated tire diameter equals the gear ratio