

# Crupi Gear Ratios

24 x 1.50 (with 24 x 1.50 tires, 22.50" inflated diameter)																			
Gear		34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51
Free Wheel	9																		
	10																		
	11	69.5																	
	12	63.8	65.6	67.5	69.4	71.3													
	13	58.8	60.6	62.3	64.0	65.8	67.5	69.2	71.0										
	14	54.6	56.3	57.9	59.5	61.1	62.7	64.3	65.9	67.5	69.1	70.7							
	15	51.0	52.5	54.0	55.5	57.0	58.5	60.0	61.5	63.0	64.5	66.0	67.5	69.0	70.5				
	16	47.8	49.2	50.6	52.0	53.4	54.8	56.3	57.7	59.1	60.5	61.9	63.3	64.7	66.1	67.5	68.9	70.3	
	17	45.0	46.3	47.6	49.0	50.3	51.6	52.9	54.3	55.6	56.9	58.2	59.6	60.9	62.2	63.5	64.9	66.2	67.5
	18	42.5	43.8	45.0	46.3	47.5	48.8	50.0	51.3	52.5	53.8	55.0	56.3	57.5	58.8	60.0	61.3	62.5	63.8
20		39.4	40.5	41.6	42.8	43.9	45.0	46.1	47.3	48.4	49.5	50.6	51.8	52.9	54.0	55.1	56.3	57.4	

Front gear size divided by the Freewheel size times the inflated tire diameter equals the gear ratio