

Crupi Gear Ratios

		24 x 1.50 (with 24 x 1.75 tires, 23" inflated diameter)																	
Gear		34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51
Free Wheel	9																		
	10																		
	11	71.1																	
	12	65.2	67.1	69.0	70.9														
	13	60.2	61.9	63.7	65.5	67.2	69.0	70.8											
	14	55.9	57.5	59.1	60.8	62.4	64.1	65.7	67.4	69.0	70.6								
	15	52.1	53.7	55.2	56.7	58.3	59.8	61.3	62.9	64.4	65.9	67.5	69.0	70.5					
	16	48.9	50.3	51.8	53.2	54.6	56.1	57.5	58.9	60.4	61.8	63.3	64.7	66.1	67.6	69.0	70.4		
	17	46.0	47.4	48.7	50.1	51.4	52.8	54.1	55.5	56.8	58.2	59.5	60.9	62.2	63.6	64.9	66.3	67.6	69.0
	18	43.4	44.7	46.0	47.3	48.6	49.8	51.1	52.4	53.7	54.9	56.2	57.5	58.8	60.1	61.3	62.6	63.9	65.2
20	39.1	40.3	41.4	42.6	43.7	44.9	46.0	47.2	48.3	49.5	50.6	51.8	52.9	54.1	55.2	56.4	57.5	58.7	

Front gear size divided by the Freewheel size times the inflated tire diameter equals the gear ratio